

# *Traditional*

## *Standard Operating Procedure*

### **1. Hot Water Rinse (160°-175°) for 3-5 minutes**

a. This will preheat the stainless steel & remove any big debris.

### **2. Mix 1oz:1gal | Caustic 6010A:Hot Water (160°-175°)**

a. If you have heavy soils, bump it up to 1 oz:1gal + Booster\*

b. If you have extra heavy soils, bump it up to 2 oz:1gal + Booster\*\*

c. Run 6010A with boosted wash cycle for 45 min.

### **3. Cold Water Rinse for 2 min**

a. This will get residual caustic off of the tank and pre-cool it.

### **4. Mix 1oz:2gal | Stronghold NP50:Warm Water (<140°)**

a. Run cycle for 30 min.

### **5. Cold Water Rinse for 2 min**

### **6. Mix 1.7-2.0oz:5gal | Oxysan:Cold Water**

a. Run Oxysan for 30 - 45 min. No need to rinse.

**ALWAYS WEAR PPE EYE-WEAR & GLOVES**

\*Booster is Hydrogen Peroxide 34.5%

\*1oz:2gal

\*\*1oz:1gal